



GILL THE CABINET LIFTER
LIFT®

Model 70



*Created by professionals
for professionals.*

For more information call,

1.800.448.0822

3

Tools in 1

**Adapts to the way
you want to install
your cabinets.**



Hang upper cabinets first

**Hang upper cabinets over
existing counter tops.**

**Goes in elevators and
through doorways**

**Functions as a dolly for rolling
base cabinets in place.**



www.telproinc.com

Upper cabinets can be installed in 3 easy steps.



1

Load upper by lifting one end and rolling lift under.



2

Balance cabinet on lift and position in front of wall.



3

Raise cabinet to desired height and mount on the wall.

Hanging upper cabinets over existing counter tops is easy as ABC!



A

Position loaded upper in front of base.



B

Carefully transfer upper cabinet to T spacers placed on base unit. (T spacers not included)



C

Raise cabinet to desired position and mount to wall.

SPECIFICATIONS:

- Made of strong light weight anodized aluminum
- Total Weight 54 lbs (24.5 kg)
- 300 lb. load capacity (136.1 kg)
- Lifting Height 70.25" (1.8 m)
- Loading Height 7.25" (18.4 cm)
- Overall height of lift 79.75" (2.03 m)
- Birch cabinet seat 12.5 long x 9 wide (31.8 x 22.9 cm)
- Dual directional self locking winch
- 3/8 Rhino-flex™ Polyester rope (4750 lbs tensile)
- Carpeted Base 18" long x 14" wide (45.7 x 35.6 cm)
- Dolly 24" x 24" x 7.25" high (61x61x18.4 cm)
- Shipping weight 70 lb. (31.8 kg)
- Dual protecting birch plywood strips
- Casters: 5" swivel ball-bearing casters (2 braking casters)



www.telproinc.com